LED WallScone



START FROM HERE

- Make sure power is completely off at the fuse box.
- Have your fixture installed by a qualified licensed electrician
- · Prepare everything in a clear area.
- Wear gloves at all times during this installation.
- · Read instructions carefully before you start assembly.
- Keep this instruction sheet for future reference.

Technical Support: 1-877-452-6858

Please Note:

- · All Kuzco LED fixtures come with pre-wired LED module(s).
- Unless instructed to do so, please do not touch any part of the LED module(s) as any unnecessary contact with the module could cause permanent damage.
- For dimming, an ELV (Electronic Low Voltage) type of dimmer is required.
- 1. Remove the fixture from its original packaging. Remove the mounting crossbar (1c) from the canopy (2b) by unthreading two screws (2a). Attach the mounting crossbar (1c) to the electrical junction box (1a), by using screws (1d) provided in the hardware package.
- 2. Attach the canopy to the mounting plate. First connect all wires correctly G ground to ground, N neutral wire (white to white), L live wire (black to black) with provided marrettes (1b) from the hardware package. Now place the canopy (2b) onto the mounting crossbar (1c). As you move the canopy, align the side holes to the holes on the mounting crossbar (1c), and secure the canopy by two screws (2a).

3. You have now completed the installation of your fixture, enjoy.



