For Style 1698P50 Assembly Instruction Sheet #S-1 698P50

Tools Required: Fisthead soverstriver, Phillips soverstriver, pliers, wire outlers, wire strippers, electrical tape, makety glassen. Light Searce: 120V LED *27W DRAWABLE (2000Q).

Properation: Identify and impact all parts before beginning installation. Chack package content list and diagrams below to be sure all parts are present. If any parts are admissing or damaged, do not extrage to assemble, install, or operate the fixture. Content outcomer service for replacement parts.

⚠ Warnings and Cautions
Tum off electricity at circuit breaker or main fuse box before installation. Consult a licensed electricism if in doubt.
These instructions are provided for your safety. It is very important you read them completely before installing the foture.
We strongly recommend that a licensed, professional electricism perform the installation.

Disconnect fixture from power source before replacing buibs. Make sure buibs are given sufficient time to cool before removal.



