LED Exterior Wall Sconce



START FROM HERE

- Make sure POWER is COMPLETELY OFF at the fuse box
- Have your fixture installed by a qualified licensed electrician
- Prepare everything in a clear area
- Wear gloves at all time during this installation
- · Read instructions carefully before you start assembly
- Keep this installation sheet for future reference

Technical Support: 1-855-855-8926

- This Kuzco LED fixtures come with pre-wired LED module(s)
- Unless instructed, Do Not touch any part of the LED module(s) as any unnecessary contact with the module could cause permanent damage
- For dimming, an ELV (Electronic Low Voltage) type of dimmer is required

- Remove fixture from its original package
- Separate mounting plate (1c) from canopy (2a) by removing the set screws with allen key (2f)
- **3.** Attach mounting plate (1c) to electrical junction box (1a) using screws provided (1e) in hardware package

- Make proper electrical connections (black to hot "L", white to neutral "N", ground to "GND") with wire nuts (1b) provided in hardware package
- **5.** Align mounting plate (1c) to holes on canopy (2a), and then attach using set screws and allen key (2f)
- **6.** To prevent moisture from entering outlet box and causing short, seal around perimeter between fixture and mounting surface with weather resistant caulking (see illustration 1)




Illustration 1.

