LED Wall Sconce



START FROM HERE

- Make sure POWER is COMPLETELY OFF at the fuse box
- Have your fixture installed by a qualified licensed electrician
- · Prepare everything in a clear area
- Wear gloves at all times during this installation
- · Read instructions carefully before you start assembly
- Keep this installation sheet for future reference

Technical Support: 1-855-855-8926

inside junction box (1a)

Please Note:

- This Kuzco LED fixture comes with pre-wired LED module(s)
- Unless instructed, Do Not touch any part of the LED module(s) as any unnecessary contact with the module could cause permanent damage
- Touch dimming
- Remove fixture from its original package
 4. Attach mounting plate (1c) to electrical junction box (1a) using screws provided (1e) in hardware package
- Remove canopy (2a) from mounting plate (1c) by turning
 Twist canopy (2a) onto mounting plate (1c) to lock in place
- Make proper electrical connections (black to hot "L", white to neutral "N", ground to "GND") with wire nuts (1b) provided in hardware package, and then place driver (1f)
 Gently slide lamp head (3c) onto magnetic connector (3d)



