Ceiling Canopy

CNL3AC
INSTALLATION SHEET

START FROM HERE

- Make sure **POWER** is **COMPLETELY OFF** at the fuse box
- Have your fixture installed by a qualified licensed electrician
- Prepare everything in a clear area
- Wear gloves at all time during this installation
- Read instructions carefully before you start assembly
- Keep this installation sheet for future reference

Technical Support: 1-855-855-8926

Please Note:
- Dimming options depends on choice of pendants

1. Remove fixture from its original package

2. Separate mounting plate **(1c)** from canopy **(2a)** by removing canopy screws **(2f)**

3. Attach mounting plate **(1c)** to electrical junction box **(1a)** using screws provided **(1e)** in hardware package

4. Secure mounting plate **(1c)** to mounting surface with additional anchors **(1f)** and screws **(1h)**

5. Remove lamp shade **(3c)** from its original package, remove canopy attached from wire

6. Bring lamp shade wires through hanging horizontal bar **(3b)** and into canopy through strain relief **(2d)**, temporarily lock set screws **(2c & 3a)** to secure. Make proper electrical connections (black to hot “L”, white to neutral “N”, ground to “GND”) with wire nuts **(1b)** provided in hardware package

7. Adjust hanging height of lamp shades **(3c)** to the desired distance from the horizontal hanging bar **(3b)** and lock into place with set screws **(3a)**. Adjust the height of the horizontal hanging bar **(3b)** to the desired distance from the canopy **(2a)** and lock into place with set screws **(2c)**

8. Cut and strip excess wire. Push lever on the terminal block **(2b)** and make the electrical connections for the lamp shades **(3c)**

9. Secure the canopy **(2a)** to the mounting plate **(1c)** using the canopy screws **(2f)**. If applicable, insert lamp **(3d)** into the socket in lamp shade **(3c)**



KUZCO
19054 28th Avenue Surrey, BC Canada V3Z 6M3
T: 604 538 7162 TF: 1-855 85 KUZCO F: 604 538 7196
W: kuzcolighting.com
20200810